



PLOW MID-MOUNT KIT

FOR POLARIS ATV's


P/N 15-3591

ASSEMBLY / OWNERS MANUAL

Application

PLOW PUSH FRAME NO. 15-0070, 33-0000 or 33-0070

Before you begin, please read these instructions and check to be sure all parts and tools are accounted for. The following instructions contain details required to install and service the contents of this kit.



INTRO

Thank you for purchasing Kolpin engineered products. With proper installation, usage, care, and maintenance, your Kolpin product will last for years to come.

BEFORE YOU BEGIN

- Your Kolpin accessory is exclusively designed for your vehicle.
- Read and understand the entire installation manual, including all installation instructions, operating instructions, safety warnings and guidelines before installing or operating your accessory. Failure to comply may result in damage to the product and / or vehicle, and can lead to hazards up to and including death.
- Verify all parts and tools are accounted for. If parts are missing, do not return to the store. Call us for help, **Toll Free 1-877-956- 5746**
- Follow all steps correctly and in the sequence described.
- Keep these instructions for future reference or for informational requests.
- To facilitate installation, make sure that your vehicle is clean and free of debris.
- All directions referring to right and left are from the rider perspective when sitting on the machine.

ASSEMBLY TIME

Approximately 14 minutes

SAFETY INFORMATION

Please read and understand all Cautions, Notices, and Warnings in this manual before you begin. In order to protect you and your ATV / UTV, certain parts of the plow system and / or hardware are designed to fail when the equipment is over-stressed.

Follow these guidelines to ensure satisfactory operation:

- Read this manual and your ATV / UTV operators manual before use.
- Periodically check for wear and tightness of all fasteners. Replace or re-torque fasteners as necessary.
- Before first use, set plow in the furthest right or left angled position to check for interference with the vehicle.
- Operate with extreme caution on slopes and rough terrain. Be familiar with the area before you plow.
- Be aware of immovable objects that could be hidden in the area you are plowing.
- To avoid damage when pushing snow into a pile, reverse direction before raising the plow blade.
- Do not ram the plow blade into piles of snow.
- For best results, set the suspension preload of your ATV / UTV to the stiffest setting.
- To reduce steering effort and increase mobility, set the air pressure of your tires to the maximum pressure specification.
- The plow skids are adjustable. General skid setting is even with the plow wear bar bottom edge, higher settings reduce the chance of rocks and gravel from being collected.
- To increase traction during plow operation, operators can try: Securing weight to the ATV / UTV for additional tire downforce, reducing tire air pressure, or installing tire chains.



WARNING



TO AVOID SERIOUS INJURY OR DEATH:

1. DO NOT EXCEED 5 MPH (8 KM/H) WITH BLADE INSTALLED
2. OPERATE WITH EXTREME CAUTION ON SLOPES, STEEP GRADES, AND ROUGH TERRAIN
3. ALLOW NO RIDERS ON BLADE OR ATV WHILE MOVING OR STATIONARY
4. KEEP BYSTANDERS AWAY FROM THE BLADE OR ATV WHILE MOVING OR STATIONARY
5. WHEN PUSHING HEAVY MATERIAL, DIRECTION CONTROL MAY BECOME DIFFICULT
6. BEFORE ADJUSTING BLADE: STOP ATV ENGINE; SET AND LOCK BRAKES; RAISE AND LOCK BLADE
7. LOWER BLADE TO DOWN POSITION WHEN BLADE AND ATV ARE NOT IN USE
8. READ BLADE INSTRUCTION SHEETS AND ATV OWNER'S MANUAL

REQUIRED SOLD SEPARATELY

Only parts for installation of the Plow Mounting Bracket Kit are included. For complete snow plow system installation, additional items are required such as a plow push frame, vehicle plow mount, winch, and winch mount. See www.Kolpin.com for products to complete your plow system.

TOOLS REQUIRED


- Safety Glasses
- Socket Set, Metric
- Torque Wrench
- Wrench Set, Metric

SPARE KIT

SPARE KITS		Hardware kit P/N CYC5780
Item	Description	
4	Clevis Pin, Zinc Plated, 10mm x 35mm	2x
5	Hair Pin, Zinc Plated, #3	2x
6	Square U-Bolt, Zinc Plated, M8-1.25 x 30mm x 70mm	2x
7	Square U-Bolt, Zinc Plated, M8-1.25 x 30mm x 50mm	2x
8	Carriage Bolt, Zinc Plated, M8-1.25 x 40mm	2x
9	Flange Locknut, Zinc Plated, M8-1.25	10x

KIT CONTENTS

Item	Qty	Part Description	Part Number
1	1	Blade Attaching Bracket	-
2	2	Support Plate	-
3	3	Spacer Plate	-
4	2	Clevis Pin, Zinc Plated, 10mm x 35mm	-
5	2	Hair Pin, Zinc Plated, #3	-
6	2	Square U-Bolt, Zinc Plated, M8-1.25 x 30mm x 70mm	-
7	2	Square U-Bolt, Zinc Plated, M8-1.25 x 30mm x 50mm	-
8	2	Carriage Bolt, Zinc Plated, M8-1.25 x 40mm	-
9	10	Flange Locknut, Zinc Plated, M8-1.25	-
10	1	Instruction Guide (not shown)	-



INSTALLATION INSTRUCTIONS





VEHICLE PREPARATION

GENERAL

1. Park vehicle on a flat surface.
2. Shift vehicle into park.
3. Turn key to OFF position and remove key.
4. To ease access for mount installation, loosen or temporarily remove the four floorboard screws for the left side floorboard. (See Illustration 1-1).

ACCESSORY INSTALLATION

5. Align the spacer plates (item #3) between the support plate (item #2) and the attaching bracket (item #1). Secure the plates together with carriage bolts (item #8) and fasten with locknut (item #10). Do not fully tighten hardware at this time. Note: Polaris Sportsman 700 requires two spacer plates on the Right side of the blade mount. All other models require only one spacer plate on the Right side of the blade mount.
6. Hang the u-bolts (item #7 and #8) over the foot rest brackets as shown. (See Illustrations 1-2 and 1-3).





ACCESSORY INSTALLATION (CONTINUED)

7. Position the attaching bracket assembly up to the u-bolts and secure with locknuts (item #9) as shown. Tighten to specification. (See Illustrations 1-5 and 1-6).

 = T
8MM FASTENER TORQUE: 17 ft. lbs. (23 Nm)

8. If removed in step 4, please reinstall and/or tighten the four left-side floor-board screws.



WARRANTY



Two Year Limited Warranty

For the period of two (2) years from the purchase date, Kolpin will replace for the original purchaser, free of charge, any part or parts found upon examination by Kolpin to be defective in material, workmanship, or both.

All transportation costs incurred submitting product to Kolpin for warranty consideration must be borne by the purchaser. If Kolpin determines that the product must be returned to the factory for credit, please call 1-877-956-5746 for a Return Merchandise Authorization (RMA) number and shipping instructions.

This warranty does not apply to parts that have been damaged by accident, alteration, abuse, improper maintenance, normal wear, or other causes beyond the manufacturer's control. In order to protect you and your ATV, certain parts of the plow system and/or hardware are designed to fail when the equipment is over-stressed. Parts that are lost due to loosening and improper maintenance are not covered under warranty. This warranty does not cover removal or reinstallation labor fees of the plow system and related components.

Peripheral products such as engines, electric motors, and actuators may carry an original manufacturer's warranty. Most hardware is general in nature and is easily obtained locally. Be sure to replace with minimum metric class 8.8 specification.

Kolpin Outdoors, Inc.

Telephone: (763)-478-5800

Toll Free: (877)-956-5746

Fax Number: (800)-245-7569

www.kolpin.com

Email: customerservice@kolpin.com